Revised
7-26-'10

OP/TECH USA®

Camera/Pouch Dimensions Chart

This reference chart shows the dimensions of our pouches by name.

OP/TECH USA Pouch Dimensions Chart 2

Camera/Pouch Recommendation Chart

This reference chart shows the recommended pouch(es) for specific camera brands and models.

CANON. 3
CASIO 5
CONCORD 6
CONTAX 7
EPSON 7
FUJI FILM 7
GE 9
HP 9
KODAK 10
KYOCERA 12
LEICA. 12
MAMIYA 13
MINOLTA 13
NIKON 14
OLYMPUS 16
PANASONIC Lumix. 18
PENTAX. 20
POLAROID 21
RICOH 22
SAMSUNG 22
SANYO 24
SIGMA. 25
SONY 25
TOSHIBA. 27

Revised
7-26-'10

OP/TECH USA®

Camera/Pouch Dimensions Chart

Chart Name	Full Product Name	Dimensions w x h x d (inches)	Dimensions w x h x d (cm)	Notes
D-Micro	Soft Pouch™ - Digital D Series, D-Micro	4.5" x 2.5" x 2"	11,43 x 6,35 x 5,08	
D-Mini	Soft Pouch™ - Digital D Series, D-Mini	4.5" x 3" x 2"	11,43 x 7,62 x 5,08	
D-Small	Soft Pouch™ - Digital D Series, D-Small	4.5" x 3" x 3.25"	11,43 x 7,62 x 8,26	
D-Compact	Soft Pouch™ - Digital D Series, D-Compact	4.8" x 3.5" x 3"	12,2 x 8,9 x 7,62	
D-M 4/3	Soft Pouch™ - Digital D Series, D-M 4/3	4.75" x 3" x 5"	12,1 x 8,9 x 12,7	
D-Offset	Soft Pouch™ - Digital D Series, D-Offset	4.9" x 3.5" x 4.6"	12,45 x 8,9 x 11,69	
D-Midsize	Soft Pouch™ - Digital D Series, D-Midsize	5" x 3.75" x 6"	12,7 x 9,53 x 15,24	
D-Midsize Zoom	Soft Pouch™ - Digital D Series, D-Midsize Zoom	5" x 3.75" x 8"	12,7 x 9,53 x 20,3	
D-Pro	Soft Pouch™ - Digital D Series, D-Pro	6" x 6.5" x 6"	15,24 x 16,5 x 15,24	
D-Pro Zoom	Soft Pouch™ - Digital D Series, D-Pro Zoom	6" x 6.5" x 8"	15,24 x 16,5 x 20,32	
D-SLR	Soft Pouch™ - Digital D Series, D-SLR	6" x 4.5" x 6"	15,24 x 11,43 x 15,24	
D-SLR Zoom	Soft Pouch™ - Digital D Series, D-SLR Zoom	6" x 4.5" x 8"	15,24 x 11,43 x 20,32	
Rangefinder	Soft Pouch™ - SLR Rangefinder	5.75" x 3.1" x 4"	14,61 x 7,87 x 10,16	
Rangefinder Tele	Soft Pouch™ - SLR Rangefinder Telephoto	5.75" x 3.1" x 6"	14,61 x 7,87 x 15,24	Fits Lenses up to 2.75" Ø
SLR AF-Pro	Soft Pouch™ - SLR AF-Pro	6" x 6" x 6"	15,24 x 15,24 x 15,24	
SLR AF-Zoom	Soft Pouch™ - SLR AF-Zoom	6.1" x 3.5" x 6.25"	15,49 x 8,9 x 15,88	
SLR Auto	Soft Pouch™ SLR - Auto	6.1" x 3.5" x 4.9"	15,49 x 8,9 x 11,68	
SLR Manual	Soft Pouch™ SLR - Manual	5.5" x 3" x 3.75"	13,97 x 7,62 x 9,53	
Euro-Mini	Soft Pouch™ - Euro-Mini	2" x 3.5" x .75"	5,1 x 8,9 x 1,9	
Mini	Soft Pouch™ Photo/Electronic - Mini	2.5" x 4" x 1	6,35 x 10,16 x 2,54	
Large	Soft Pouch™ Photo/Electronic - Large	4" x 7" x 1.5"	10,16 x 17,78 x 3,81	
WB-Mini	Soft Pouch™ Photo/Electronic - Wide Body Mini	2.75" x 4.5" x 1.25"	6,99 x 11,43 x 3,18	
WB-S	Soft Pouch™ Photo/Electronic - Wide Body Small	3" x 4" x 2.25"	7,62 x 10,16 x 5,72	
WB-Med	Soft Pouch™ Photo/Electronic - Wide Body Medium	3" x 5" x 2.5"	7,62 x 12,7 x 6,35	
Milli	Soft Pouch™ PDA/Cam - Milli	3" x 4.75" x .75	7,62 x 12,07 x 1,9	
Micro	Soft Pouch™ PDA/Cam - Micro	3.375" x 5.25" x 1"	9,53 x 13,34 x 2,54	
Macro	Soft Pouch™ PDA/Cam - Macro	3.75" x 5.75" x 1	9,53 x 14,61 x 2,54	
Snappeez - S	Soft Pouch™ Snappeez - Small	2" x 3.5" x .5"-.75"	5,08 x 8,9 x 1,27-1,9	
Snappeez - M	Soft Pouch™ Snappeez - Medium	2.5" x 3.5" x .75"-1.25"	6,35 x 8,9 x 1,9-3,18	
Snappeez - L	Soft Pouch™ Snappeez - Large	2.5" x 4.5" x .9"-1.5"	6,35 x 11,43 x 2,29-3,81	
Snappeez H - M	Soft Pouch™ Snappeez - Horizontal Medium	3.75" x 2.5" x .25"-.75"	9,5 x 6,3 x ,6-1,9	
Snappeez H - L	Soft Pouch™ Snappeez - Horizontal Large	4.5" x 2.5" x .25"-.75"	11,4 x 6,3 x ,6-1,9	
Snappeez WB H - M	Soft Pouch™ Snappeez - Wide Body Horizontal Medium	3.75" x 2.5" x .75"-1.25"	9,5 x 6,3 x 1,9-3,2	
Snappeez WB H - L	Soft Pouch™ Snappeez - Wide Body Horizontal Large	4.5" x 2.5" x .75"-1.25"	11,4 x 6,3 x 1,9-3,2	
Zippeez-S	Soft Pouch™ Zippeez Small	4" x 2.75" x 1"	10,16 x 6,99 x 2,54	
Zippeez-M	Soft Pouch™ Zippeez Medium	4.5" x 3" x 1.5"	11,43 x 7,62 x 3,81	
Zippeez-L	Soft Pouch™ Zippeez Large	5.5" x 3.5" x 1.75"	13,97 x 8,9 x 4,45	
Hipster-S	Hipster Pouch - Small	4" x 3" x 1"	10,16 x 7,62 x 2,54	Front Pocket Depth is .5"
Hipster-M	Hipster Pouch - Medium	4.5" x 3" x 1.5"	11,43 x 7,62 x 3,81	Front Pocket Depth is .5"
Hipster-L	Hipster Pouch - Large	5.5" x 3.5" x 1.75	13,97 x 8,9 x 4,45	Front Pocket Depth is .75"
Hipster-XL	Hipster Pouch - Extra-Large	6" x 4" x 2.5	15,24 x 10,16 x 6,35	Front Pocket Depth is .75"
Body Covers				
Manual Body Cover	Manual Body Cover	5.75" x 3" x 2"	14,6 x 7,6 x 5	
Auto Body Cover	Auto Body Cover	6" x 4.5" x 3"	15,24 x 11,43 x 7,62	
AF-Pro Body Cover	AF-Pro Body Cover	6" x 6.5" x 3"	15,24 x 16,51 x 7,62	

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
CANON	A1100 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	A2100 IS	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	A470	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	A480	Mini, Zippeez-S, Hipster-S, Snappeez-M
	A580/ A590 IS	WB-Mini, Zippeez-M, Hipster-M
	A630/ A640	Zippeez-M, Hipster-M
	A710IS	WB-S, Zippeez-M, Hipster-M
	D10	WB-Small, Zippeez-M, Hipster-M
	Elura 50	Hipster-XL
	EOS 1000D / Rebel XS	D-Midsize
	EOS 10D/ 20D	D-SLR
	EOS 1D Mark II / 1Ds Mark II / 1D Mark II N/ Mark III	D-Pro
	EOS 1Ds Mark III/ Mark IV	D-Pro
	EOS 20Da	D-SLR
	EOS 3	D-SLR
	EOS 300D	D-SLR
	EOS 30D	D-SLR
	EOS 400D/ Digital Rebel XTi	D-Midsize
	EOS 40D	D-SLR
	EOS 450D/ Rebel XSi	D-Midsize
	EOS 500D	D-Midsize
	EOS 50D	D-SLR
	EOS 550D	D-Midsize
	EOS 5D	D-SLR
	EOS 5D Mark II	D-SLR
	EOS 7D	D-SLR
	EOS D30/D60	D-SLR
	EOS Digital Rebel	D-SLR
	EOS Digital Rebel XT	D-Midsize
	EOS ELAN 7 / 7E, 7N / 7NE	SLR Auto, SLR AF Zoom, D-SLR
	EOS REBEL 2000	SLR Auto
	EOS REBEL G, G11	SLR Auto
	EOS REBEL K2	D-Midsize
	EOS REBEL T1i	D-Midsize
	EOS REBEL T2	D-Midsize
	EOS Rebel T2i	D-Midsize
	EOS REBEL Ti	D-Midsize
	EOS-1Ds	D-Pro
	EOS-1V / 1VHS	D-SLR
	Ixus 105	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	IXUS 110 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	IXUS 120 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Revised
7-26-'10

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
CANON (continued)	Ixus 130	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	IXUS 200 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	IXUS 300 HS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	IXUS 210	Mini, Zippeez-S, Hipster-S, Snappeez-M
	IXUS 430	Mini, Zippeez-S, Hipster-S, Snappeez-M
	IXUS 990 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot A1000 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot A2000 IS	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	Power Shot A3000 IS/ A3100 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot A40	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	Power Shot A410	WB-Mini, Zippeez-M, Hipster-M
	Power Shot A420/ 430	WB-Mini, Zippeez-M, Hipster-M
	Power Shot A450/ A460	WB-Mini, Zippeez-M, Hipster-M
	Power Shot A490/ A495	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot A510/ A520	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot A530/ A540/ A550/ A560/ A570IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot A610 / A620	WB-Small, Zippeez-M, Hipster-M
	Power Shot A650 IS/ A720 IS	WB-Small, Zippeez-M, Hipster-M
	Power Shot A700	WB-Small, Zippeez-M, Hipster-M
	Power Shot A80/ A85/ A95	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	Power Shot E1	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	Power Shot G10	WB-Small, Hipster-M, D-Mini, Zippeez-L
	Power Shot G11	WB-Small, Hipster-M, D-Mini, Zippeez-L
	Power Shot G6	D-Small
	Power Shot G6 w/ extended lens	D-Offset
	Power Shot G7	WB-Small, Zippeez-M, Hipster-M
	Power Shot G9	WB-Small, Zippeez-M, Hipster-M, D-Mini
	Power Shot Pro1	D-Offset
	Power Shot Pro90 IS	D-Offset
	Power Shot S1 IS	D-Small
	Power Shot S2 IS/ S3 IS	D-Small
	Power Shot S5 IS	D-Compact
	Power Shot S60/ S70/ S80	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	Power Shot S90	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot SD 1000/ IXUS 70	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	Power Shot SD 750/ IXUS 75	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	Power Shot SD1300 IS	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	Power Shot SD1400 IS	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	Power Shot SD20, SD200	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	Power Shot SD30/ SD40/ IXUS i7	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	Power Shot SD300/ SD400 /SD450/ SD500	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	Power Shot SD3500 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
CANON (continued)	Power Shot SD430	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	Power Shot SD4000 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot SD550	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot SD600/ IXUS 60	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	Power Shot SD630/ IXUS 65	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	Power Shot SD700 IS / IXUS800 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot SD770	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	Power Shot SD790	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	Power Shot SD800 IS/ IXUS 850 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot SD850 IS/ IXUS 950 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot SD870 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot SD880 IS/ IXUS 870 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot SD890 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot SD900 / IXUS 900 Ti	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot SD950 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot SD990 IS/ IXUS 980 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Power Shot SX10 IS/ SX1 IS	D-Offset
	Power Shot SX100 IS	Zippeez-M, Hipster-M
	Power Shot SX110 IS	D-Small
	Power Shot SX120 IS	D-Small
	Power Shot SX20 IS	D-Compact
	Power Shot SX210 IS	Zippeez-M, Hipster-M, Snappeez-L
	Power Shot TX1	Mini, Zippeez-S, Hipster-S, Snappeez-M
	SD1200 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	SD780 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	SD960 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	SSD970 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	SX200 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
CASIO	EX-F1	D-Offset
	EX-FC100	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-FH10	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-FH100	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-FH20, EX-FH25	D-Compact
	EX-FS10	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-G1	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-H5	WB Mini, Zippeez-M, Hipster-M, Snappeez-L
	EX-H10	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-H15	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-M2, EX-S2	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	EX-M20U, S20U	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	EX-P505	Zippeez-M, Hipster-M
	EX-P600 / EX-P700	WB-S, Zippeez-M, Hipster-M

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Revised
7-26-'10

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
CASIO (continued)	EX-QVR52	Mini, Zippeez-M, Hipster-M, Snappeez-M
	EX-S10	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	EX-S100	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-S12	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-S3	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	EX-S5	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-S500/ EX-S600D	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	EX-S600	WB-S, Zippeez-M, Hipster-S
	EX-S7	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-S880	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	EX-V7/ V8	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-X1050	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z10/ EX-Z110/ EX-Z120	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z100/ Z200	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z1000	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z1080	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z1200/ EX-Z1200SR	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z2000	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z250	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z270	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z280	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z29	Milli, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z30/ EX-Z4U	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	EX-Z300	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z33	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	EX-Z35	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z40 / EX-Z50 / EX-Z55 / EX-Z57	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z400	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z450	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z5/ EX-Z70	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z500/ EX-Z700	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	EX-Z550	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z60	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z600/ EX-Z750/ EX-Z850	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z75	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z77	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z80	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	EX-Z85	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	EX-Z9	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX-Z90	Mini, Zippeez-S, Hipster-S, Snappeez-M
	QV-R40/ QV-R41/ QV-R51/ QV-R62	Mini, Zippeez-M, Hipster-M, Snappeez-M
CONCORD	4042,	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
CONCORD (continued)	5040,	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	5042,	Mini, Zippeez-S, Hipster-S, Snappeez-M
	5062 AF	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	5340z	Mini, Zippeez-S, Hipster-S
	6340z	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	642 VGA/ 642	Mini, Zippeez-S, Hipster-S,
	Duo LCD	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	DV2020	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	DVx	Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	ES500z/ ES510z	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	Go LCD	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Q 1000	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	Q DVO 2000	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	Q Go 2000	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Q Go 2CD	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Q Mini	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	Q-2040	WB-Mini, Zippeez-L, Hipster-L, Snappeez-L
	Q-3040 AF	Mini, Zippeez-M, Hipster-M, Snappeez-L
	Q-3340z	WB-Mini, Zippeez-M, Hipster-M
	Q-3341z	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	Q-4060 AF	WB-Mini, Zippeez-M, Hipster-M
	Q-5345z	Mini, Zippeez-M, Hipster-M, Snappeez-M
CONTAX	Aria	SLR Manual
	G2	Rangefinder
	I4R	Zippeez-S, Hipster-S, Snappeez-S
	N1	D-SLR, D-SLR Zoom, Auto Body Cover
	NX	D-SLR, D-SLR Zoom, Auto Body Cover
	RTS III	D-SLR, D-SLR Zoom, Auto Body Cover
	SL300R T*	Mini, Snappeez-M, Snappeez Horizontal-M
	U4R	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L, Snappeez Horizontal-L
EPSON	3000 Zoom/ 3100 Zoom	D-Small
	L-200/ L-300/ L-400/ L-410	Milli, Zippeez-S, Hipster-S, Snappeez-M
	L-500V	Mini, Zippeez-S, Hipster-S, Snappeez-M
	RD-1/ RD-1s	Rangefinder
FUJI FILM	2650	WB-S, Zippeez-M, Hipster-M
	2800/ 3800	Zippeez-L, Hipster-L
	3D W1	Micro, Zippeez-L, Hipster-L
	A100	Mini, Zippeez-S, Hipster-S, Snappeez-M
	A101	WB Mini, Zippeez-M, Hipster-M, Snappeez-M
	A150	Mini, Zippeez-S, Hipster-S, Snappeez-M
	A170 / A220	Mini, Zippeez-S, Hipster-S, Snappeez-M
	A203	Mini, Zippeez-S, Hipster-S, Snappeez-M

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Revised
7-26-'10

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
FUJI FILM (continued)	A205/ A210	WB-S, Zippeez-M, Hipster-M
	A303	Mini, WB-Mini, Snappeez-L
	A310/ A330/ A340	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	A345/ A350	Mini, Zippeez-S, Hipster-S, Snappeez-M
	A400/ A500/ A600/ A700	Mini, Zippeez-S, Hipster-S, Snappeez-M
	A800/ A610	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	A820/ A900	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	A850	Mini, Zippeez-S, Hipster-S, Snappeez-M
	A920	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	AX200 / AX205	Mini, Zippeez-S, Hipster-S, Snappeez-M
	AX250	Mini, Zippeez-S, Hipster-S, Snappeez-M
	E500/ E510/ E550/ E900	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	F10/ F20/ F30/ F31fd	Mini, Zippeez-S, Hipster-S, Snappeez-M
	F100fd	Mini, Zippeez-S, Hipster-S, Snappeez-M
	F200 EXR	Mini, Zippeez-S, Hipster-S, Snappeez-M
	F300ERX/ F305EXR	Mini, WB-Mini, Snappeez-L
	F40fd	Mini, Zippeez-S, Hipster-S, Snappeez-M
	F410	Mini, Zippeez-S, Hipster-S, Snappeez-M
	F440/ F450	Mini, Zippeez-S, Hipster-S, Snappeez-M
	F460/ F470	Mini, Zippeez-S, Hipster-S, Snappeez-M
	F480	Mini, Zippeez-S, Hipster-S, Snappeez-M
	F50fd	Mini, Zippeez-S, Hipster-S, Snappeez-M
	F600 Zoom	Mini, Zippeez-S, Hipster-S, Snappeez-M
	F60fd	Mini, Zippeez-S, Hipster-S, Snappeez-M
	F650 Zoom	Mini, WB-Mini, Snappeez-L
	F700	Mini, Zippeez-M, Hipster-M, Snappeez-L
	F70EXR	Mini, Zippeez-S, Hipster-S, Snappeez-M
	F80EXR / F85EXR	Mini, Zippeez-S, Hipster-S, Snappeez-M
	HS10 / HS11	D-Midsize
	IS-1	D-Midsize
	IS-Pro	D-SLR
	J10/ J50	Mini, Zippeez-S, Hipster-S, Snappeez-M
	J100/ J110W/ J120/ J150W	Mini, Zippeez-S, Hipster-S, Snappeez-M
	J20/ J20fd	Mini, Zippeez-S, Hipster-S, Snappeez-M
	J250	Mini, Zippeez-S, Hipster-S, Snappeez-M
	J30 / J38	Mini, Zippeez-S, Hipster-S, Snappeez-M
	JX530	Mini, Zippeez-S, Hipster-S, Snappeez-M
	JZ310	Mini, Zippeez-S, Hipster-S, Snappeez-M
	S1000fd	D-Midsize
	S100fs	D-Midsize
	S1500/ S1500fd	D-Small, Zippeez-L, Hipster-L
	S1600 / S1770	D-Small

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
FUJI FILM (continued)	S1730	D-Small
	S2 Pro	D-SLR Pro
	S20 Pro	D-Offset
	S2000HD	D-Small
	S200EXR	D-Midsize
	S2500HD	D-Small
	S2500HD / S2600HD / S2900HD	D-Small
	S3 Pro	D-SLR Pro
	S3000, S3100	D-Small
	S5 Pro	D-SLR
	S5000, S5100	D-Small
	S5200	D-Offset
	S5800	D-Small
	S602	D-Offset
	S6500fd	D-Midsize
	S700	D-Small
	S7000	D-Offset
	S8000fd/ S810fd	D-Small
	S9000	D-Midsize
	S9600/ S9100	D-Midsize
	V10	Mini, Zippeez-S, Hipster-S, Snappeez-M
	XP10 / XP11	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Z1	Mini, Zippeez-S, Hipster-S, Snappeez-S
	Z100fd	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Z10fd	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Z10fd/ Z20fd/ Z200fd	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	Z3	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Z30/ Z30fd	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Z300	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Z33WP	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Z35 / Z37	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Z5fd	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Z70 / Z71	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Z700EXR / Z707EXR	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Z800ERX/ Z808EXR	Mini, Zippeez-S, Hipster-S, Snappeez-M
GE	A730/ A830	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	E1050	Mini, Zippeez-S, Hipster-S, Snappeez-M
	E850/ E1030/ E1040/ E1240	Mini, Zippeez-M, Hipster-M, Snappeez-M
	G1	Mini, Zippeez-S, Hipster-S, Snappeez-M
	X1	D-Small
HP	PhotoSmart 120	WB-Mini, Zippeez-M, Hipster-M
	PhotoSmart 215	WB-Med, Zippeez-L, Hipster-L

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Revised
7-26-'10

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
HP (continued)	PhotoSmart 315	Zippeez-L, Hipster-L
	PhotoSmart 315xi	WB-Med, Zippeez-L, Hipster-L
	PhotoSmart 318/ 318xi/ 320/ 320xi	Zippeez-M, Hipster-M
	PhotoSmart 435 (Q3731A)/ 435xi	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	PhotoSmart 612/ 612xi	WB-Med, Zippeez-L, Hipster-L
	PhotoSmart 618/ 618xi	WB-Med, Zippeez-L, Hipster-L
	PhotoSmart 620/ 620xi	WB-Med, Zippeez-L, Hipster-L
	PhotoSmart 635 (Q2224A)/ 635xi	Zippeez-M, Hipster-M
	PhotoSmart 715/ 715xi	WB-Med, Zippeez-L, Hipster-L
	PhotoSmart 720/ 720xi	WB-Med, Zippeez-L, Hipster-L
	PhotoSmart 735 (Q2210A)/ 735xi	WB-S, Zippeez-M, Hipster-M
	PhotoSmart 812/ 812xi	WB-S, Zippeez-M, Hipster-M
	PhotoSmart 850/ 850xi	D-Small
	PhotoSmart 935 (Q2214A)/ 935xi	WB-S, Zippeez-M, Hipster-M
	PhotoSmart 945 (Q2200A)/ 945xi	D-Compact
	PhotoSmart C200/ C200xi	WB-Med, Zippeez-L, Hipster-L
	PhotoSmart C500/ C500xi	WB-Med, Zippeez-L, Hipster-L
	PhotoSmart C912	SLR-Auto
	PhotoSmart E317/ E327	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PhotoSmart E337	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PhotoSmart M22/ M23	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PhotoSmart M307/ M407	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	PhotoSmart M417/ M517	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	PhotoSmart M425/ M525/ M527	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PhotoSmart M437	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PhotoSmart M537	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PhotoSmart M607/ R607xi	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PhotoSmart M707/ R707xi	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	PhotoSmart Mz67	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	PhotoSmart R507	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PhotoSmart R607	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PhotoSmart R707	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	PhotoSmart R717	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	PhotoSmart R725/ R727	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PhotoSmart R742	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PhotoSmart R817/ R818	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PhotoSmart R837	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PhotoSmart R927/ R967	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PhotoSmart R937	PDA/Cam Milli, Zippeez-M, Hipster-M
KODAK	Advantix T700	Mini, Zippeez-S, Hipster-S, Snappeez-M
	C180/ C182	Mini, Zippeez-S, Hipster-S, Snappeez-M
	C190	Mini, Zippeez-S, Hipster-S, Snappeez-M

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
KODAK (continued)	C300/ C310	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	C330/ C340	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	C360	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	C433	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	C513	Mini, Zippeez-S, Hipster-S, Snappeez-M
	C530	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	C533	WB-Mini, Zippeez-M, Hipster-M
	C613	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	C643	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	C653	Mini, Zippeez-S, Hipster-S, Snappeez-M
	C663	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	C743	WB-Mini, Zippeez-S, Hipster-S, Snappeez-M
	C763	Mini, Zippeez-S, Hipster-S, Snappeez-M
	C875	Mini, Zippeez-S, Hipster-S, Snappeez-M
	CD1013	Mini, Zippeez-S, Hipster-S, Snappeez-M
	CD80/ CD82	Mini, Zippeez-S, Hipster-S, Snappeez-M
	CD90/ CD93	Mini, Zippeez-S, Hipster-S, Snappeez-M
	CX6200/ CX6230/ CX6330	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	CX7220/ CX7300/ CX7330	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	CX7430/ CX7530/ CX7525	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	DX4530/ DX6340/ DX6440	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	DX6490	D-Small
	DX7440	WB-Mini, Zippeez-M, Hipster-M
	DX7590	D-Small
	DX7630	WB-S, Zippeez-M, Hipster-M
	EasyShare-One	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	LS443	Zippeez-L, Hipster-L
	LS743/ LS753	Mini, Zippeez-M, Hipster-M, Snappeez-L
	M1033	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	M341/ M381	Mini, Zippeez-S, Hipster-S, Snappeez-M
	M753/ M853	Mini, Zippeez-S, Hipster-S, Snappeez-M
	M763/ M863	Mini, Zippeez-S, Hipster-S, Snappeez-M
	M873/ M883	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	M893 IS	Mini, Zippeez-S, Hipster-S, Snappeez-M
	P712	D-Small
	P850	D-Small
	P880	D-Offset
	V1073/ V1273	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	V1233	Milli, Zippeez-S, Hipster-S, Snappeez-M
	V1253	Mini, Zippeez-S, Hipster-S, Snappeez-M
	V530	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	V550	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Revised
7-26-'10

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
KODAK (continued)	V570/ V705	Mini, Zippeez-S, Hipster-S, Snappeez-M
	V603	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	V610	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	V803/ V1003	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	Z1012 IS	D-Small
	Z1085 IS/ Z1285/ Z8612	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Z1275	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Z1485 IS	WB-Mini, Zippeez-M, Hipster-M
	Z612	D-Small
	Z650	D-Small
	Z700	WB-S, Zippeez-M, Hipster-M
	Z705	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	Z710 Zoom	D-Small
	Z712 IS	D-Small
	Z730/ Z760	WB-Mini, Zippeez-M, Hipster-M
	Z740	D-Small
	Z7590	D-Small
	Z812 IS	WB-M, Zippeez-L, D-Compact
	Z8612 IS	D-Small
	Z885	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Z915	WB-Small, Zippeez-M, Hipster-M, Snappeez-L
	Z950	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	Z980 IS	NA
	ZD15	WB-Small, Zippeez-M, Hipster-M, Snappeez-L
	ZD710	D-Small
	Z981	D-Offset
KYOCERA	Dental Eye III	None available at this time.
	L3v	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	L4v	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	S5R	Mini, Zippeez-S, Hipster-S, Snappeez-M
	SL300R	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
LEICA	C-LUX 1	Eurro Mini, Zippeez-S, Hipster-S, Snappeez-S
	C-Lux 3	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Digilux	WB-Med, Zippeez-L, Hipster-L
	Digilux 1	D-Compact
	Digilux 2	SLR Auto
	Digilux 3	SLR Auto
	Digilux 4.3	Zippeez-M, Hipster-M
	Digilux Zoom	Zippeez-M, Hipster-M
	Digital Module R	D-Pro
	D-Lux	SLR Manual
	D-LUX 2	Zippeez-M, Hipster-M, Snappeez-L

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
LEICA (continued)	D-Lux 3	Zippeez-M, Hipster-M, Snappeez-L
	D-Lux 4	WB Mini, Zippeez-M, Hipster-M, Snappeez-L, D-Micro
	M3/ M6/ M6 TTL/ M7	Rangefinder
	M8/ M8.2/ M9	Rangefinder
	MP	Rangefinder
	R8/ R9	D-SLR
	S2	D-SLR
	V-Lux 1	D-SLR
	V-Lux 20	WB Mini, Zippeez-M, Hipster-M, Snappeez-L
	X1	Zippeez-L, Hipster-L
MAMIYA	ZD	unkown
MINOLTA	AF 35 Bigfinder/ AF 50 Bigfinder	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	Dimage 2300	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	Dimage 2330 Zoom	WB-Med, Zippeez-L, Hipster-L
	DiMAGE 5	D-Offset
	DiMAGE 7/ 7Hi/ 7i	D-Offset
	DiMAGE A1/ A2/ A200	D-Offset
	DiMAGE E201	WB-Med, Zippeez-L, Hipster-L
	DiMAGE E223	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	DiMAGE E323	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	DiMAGE EX1500 Wide	WB-Med, Zippeez-L, Hipster-L
	DiMAGE EX1500 Zoom	WB-Med, Zippeez-L, Hipster-L
	DiMAGE F100/ F200/ F300	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	DiMAGE G400/ G500/ G530/ G600	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DiMAGE RD 3000	D-SLR
	DiMAGE S304/ S404/ S414	WB-Med, Zippeez-L, Hipster-L
	DiMAGE X/ Xg/ Xi/ Xt/ Xt Biz	Mini, Zippeez-S, Hipster-S
	Dimage X1	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	DiMAGE X20/ X31/ X50	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DiMAGE X60	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	DiMAGE Z1/ Z2/ Z3	D-Small
	DiMAGE Z10/ Z20	D-Offset
	DiMAGE Z5	D-Offset
	Dimage Z6	D-Offset
	Maxxum 3 Date	D-Midsize
	Maxxum 4/ Maxxum 5	D-Midsize
	Maxxum 5D	D-Midsize
	Maxxum 7	SLR-Auto
	Maxxum 70	D-Midsize
	Maxxum 7D	D-SLR
	Maxxum 9	D-SLR
	Maxxum HTsi Plus	D-Midsize

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Revised
7-26-'10

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
MINOLTA (continued)	Maxxum Qtsi/ Stsi/ Xtsi	D-Midsize
	Vectis S1	D-Midsize
	Vectis S100	D-Compact
	X Series x 370s	SLR-Manual
NIKON	COOLPIX 2000	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	COOLPIX 2100/ 2200	WB-Mini, Zippeez-M, Hipster-M
	COOLPIX 2500	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	COOLPIX 3100/ 3200/ 4100	WB-Mini, Zippeez-M, Hipster-M
	COOLPIX 3500	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	COOLPIX 3700	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX 4200	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX 4300	WB-Sm, Zippeez-M, Hipster-M
	COOLPIX 4500	WB-Med, Zippeez-L, Hipster-L
	COOLPIX 4600/ 5600/ 7600	WB-Mini, Zippeez-M, Hipster-M
	COOLPIX 4800	WB-Sm, Zippeez-M, Hipster-M
	COOLPIX 5000	WB-Med, Zippeez-L, Hipster-L
	COOLPIX 5200	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX 5400	WB-M, Zippeez-L, D-Compact
	COOLPIX 5700	D-Offset
	COOLPIX 5900/ 7900	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	COOLPIX 775	WB-Mini,Zippeez-M, Hipster-M
	COOLPIX 8400	D-Small
	COOLPIX 8700	D-Offset
	COOLPIX 880	WB-Sm, Zippeez-M, Hipster-M
	COOLPIX 8800	D-Offset
	COOLPIX 885	WB-Sm, Zippeez-M, Hipster-M
	COOLPIX 995	Macro, Zippeez-L, Hipster-L
	COOLPIX L1	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	COOLPIX L10/ L11/ L12	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX L100	D-Small
	COOLPIX L110	D-Small
	COOLPIX L15/ L14	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX L16/ L18	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX L19	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX L2/ L3	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX L20	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX L21	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX L22	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	COOLPIX L4	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX L5	WB-S, Zippeez-M, Hipster-M
	COOLPIX L6	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX P1/ P2	Mini, Zippeez-S, Hipster-S

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
NIKON (continued)	COOLPIX P100	D-Offset
	COOLPIX P3	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX P50	WB-S, Zippeez-M, Hipster-M
	COOLPIX P5000	WB-S, Zippeez-M, Hipster-M
	COOLPIX P5100	WB-S, Zippeez-M, Hipster-M
	COOLPIX P60	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX P6000	WB-Sm, Zippeez-M, Hipster-M
	COOLPIX P80	D-Compact
	COOLPIX P90	D-Offset
	COOLPIX S1/ S2/ S3	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S10	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	COOLPIX S1000PJ	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S200/ S210	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	COOLPIX S220	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	COOLPIX S230	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S3000	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S4	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	COOLPIX S4000	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S5	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S500	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	COOLPIX S51	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S510	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	COOLPIX S51c	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S52/ S52C	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S520	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	COOLPIX S560	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	COOLPIX S570	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S6	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S60	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S600	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	COOLPIX S6000	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S610/ S610C	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S620	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	COOLPIX S630	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S640	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S70	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S700	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	COOLPIX S710	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S7c	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX S8000	Mini, Zippeez-M, Hipster-M, Snappeez-L
	COOLPIX S9	Mini, Zippeez-S, Hipster-S, Snappeez-M
	COOLPIX SQ	None available at this time.

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Revised
7-26-'10

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
NIKON (continued)	D100	D-SLR, D-Pro (with battery pack)
	D1H/ D1X	D-PRO
	D200	D-SLR
	D2H/ D2Hs/ D2X/ D2Xs	D-PRO
	D3/ D3X/ D3s	D-PRO
	D300 / D300S	D-SLR
	D3000	D-Midsize
	D40/ D40X/ D60	D-Midsize
	D50	D-Midsize
	D5000	D-Midsize
	D70	D-SLR
	D700	D-SLR
	D70s	D-SLR
	D80/ D90	D-Midsize
	F100	D-SLR
	F3HP	SLR Manual
	F5	SLR AF-Pro
	F6 Film SLR	D-SLR
	FM10/ FM2N/ FM3A	SLR Manual
	N55/ N75	D-Midsize
	N60/ N70	SLR Auto
	N65/ N80	SLR Auto
	N90s	D-SLR
	Nikonos-V	SLR Auto
OLYMPUS	E-3	D-SLR
	E-30	D-SLR
	E-330	D-Midsize
	E-400/ E-410/ E-420/ E-430 E-450	D-Midsize
	E-500	D-Midsize
	E-510/ E-520	D-Midsize
	E-620	D-Midsize
	E-P1/ E-P2	D-M 4/3
	FE 4030/ 4040	Mini, Zippeez-S, Hipster-S, Snappeez-S
	FE 45	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE 47	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE 5030	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-100/ FE-110/ FE-115	WB Mini, Zippeez-M, Hipster-M
	FE-115	Mini, Zippeez-S, Hipster-S, Zippeez-M
	FE-120	WB Mini, Zippeez-M, Hipster-M, Snappeez-L
	FE-130/ FE-140	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-150	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-170	Mini, Zippeez-S, Hipster-S, Snappeez-M

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
OLYMPUS (continued)	FE-180	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-190	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	FE-20	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-200	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-210	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-240/ FE-250/ FE-230	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	FE-26 / FE-46	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-270	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-280	Mini, Zippeez-S, Hipster-S, Snappeez-S
	FE-290	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-300	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-3000/ 3010	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-310	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-340	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-350	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-360/ FE370	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-4000 / FE-5020	Mini, Zippeez-S, Hipster-S, Snappeez-M
	FE-5000/ 5010	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Ferrari 2004	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	Mju 1040	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Mju 1050	Mini, Zippeez-S, Hipster-S, Snappeez-M
	mju 1060	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Mju 5010	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Mju 550WP / Stylus 550WP	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Mju 7000 / Stylus 7000	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Mju 7030	Mini, Zippeez-S, Hipster-S, Snappeez-S
	Mju 7040	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Mju 9000 / Stylus 9000	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Mju 9010	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Mju Tough 3000/ 6000 / 8000	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Mju Tough 6020	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Mju Tough 8010	Mini, Zippeez-S, Hipster-S, Snappeez-M
	SP 320	WB Mini, Zippeez-M, Hipster-M, Snappeez-M
	SP 600 UZ	D-Offset
	SP 800 UZ	D-Offset
	SP-310/ SP-320/ SP-350	WB Mini, Zippeez-M, Hipster-M, Snappeez-M
	SP-500 UZ	WB-M, Zippeez-L, D-Compact
	SP-510 UZ	D-Small
	SP-550 UZ	D-Compact
	SP-560 UZ	D-Compact
	SP-565 UZ	D-Compact
	SP-570 UZ	D-Compact

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Revised
7-26-'10

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
OLYMPUS (continued)	SP-590 UZ	D-Offset
	SP-700	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylis 820	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus 1000/ 1010/ 1020	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus 1030 SW / Tough	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus 1050 SW / Tough	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus 1200	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus 600	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus 700	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus 710/ 720SW/ 725SW	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus 730	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus 740/ 750	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	Stylus 760	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus 770 SW / Tough	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus 780	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus 790 SW / Tough	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus 800	WB Mini, Zippeez-M, Hipster-M, Snappeez-L
	Stylus 810	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus 830/ 840	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus 850 SW / Tough	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus u 7010	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus u Tough 6010	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Stylus Verve / Verve S	Mini, Zippeez-S, Hipster-S, Snappeez-M
	T-100	Mini, Zippeez-S, Hipster-S, Snappeez-M
	X-560 WP	Mini, Zippeez-S, Hipster-S, Snappeez-M
PANASONIC Lumix	DMC-F1K/ DMC-F1S	Mini, Zippeez-S, Hipster-S,Euro-S
	DMC-FP1/ DMC-FP2/ DMC-FP1	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-FP8	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-FS10/ FS11	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-FS12	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-FS25	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-FS30/ FS33	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-FS42	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-FS5/ FS20	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-FS6/ FS7/ FS15	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	DMC-FS62	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	DMC-FX700	Mini, Zippeez-M, Hipster-M, Snappeez-L
	DMC-FT1	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-FT2	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-FX01/ FX07	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	DMC-FX1/ FX3/	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	DMC-FX10/ FX12	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
PANASONIC	DMC-FX100/ FX150	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
Lumix	DMC-FX30	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
(continued)	DMC-FX33/ FX35/ FX37	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	DMC-FX40	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	DMC-FX5	Mini, Zippeez-M, Hipster-M, Euro-S
	DMC-FX50	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-FX500	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	DMC-FX55	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	DMC-FX550	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	DMC-FX60 / FX65	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-FX66	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	DMC-FX7/ FX7K	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	DMC-FX70 / FX75	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-FX8K/ FX8S/ FX9K/ FX9S	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	DMC-FZ10K/ DMC-FZ10S	SLR Auto
	DMC-FZ15K	SLR Manual
	DMC-FZ18	D-Offset
	DMC-FZ1K/ DMC-FZ1S	D-Small
	DMC-FZ20K/ FZ20S	SLR Manual
	DMC-FZ28	D-Offset ??????
	DMC-FZ3/ FZ4/ FZ5/ FZ5K/ FZ5S/ FZ4S	D-Small
	DMC-FZ30K/ FZ30S/ FZ50	D-Midsize
	DMC-FZ35 / FZ38	D-Offset ??????
	DMC-FZ7K/ FZ7S	D-Small
	DMC-FZ8	D-Small
	DMC-FZ40/ FZ45	D-Offset
	DMC-FZ100	D-Offset
	DMC-G1 / G2 / G10	D-Midsize
	DMC-GF1	D-M 4/3
	DMC-GH1	D-Midsize
	DMC-L1	SLR Auto
	DMC-L10	D-Midsize
	DMC-LC1	Rangefinder
	DMC-LC33/ DMC-LC43/ DMC-LC50	WB Mini, Zippeez-M, Hipster-M, Snappeez-M
	DMC-LC5K/ DMC-LC5S	D-Midsize
	DMC-LC70/ DMC-LC80	WB Mini, Zippeez-M, Hipster-M, Snappeez-M
	DMC-LS1	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-LS2S	Zippeez-M, Hipster-M, Snappeez-L
	DMC-LS60/ LS70/ LS75	Milli, Zippeez-S, Hipster-S, Snappeez-M
	DMC-LS80	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-LX1K/ LX1S/ LX2/ LX3	Zippeez-M, Hipster-M, D-Micro
	DMC-LX5	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Revised
7-26-'10

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
PANASONIC Lumix (continued)	DMC-LZ1/ LZ2	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-LZ3S/ LZ5K/ LZ5S	WB Mini, Zippeez-M, Hipster-M
	DMC-LZ6/ LZ7/ LZ8/ LZ10	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-TS10	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-TZ1	Zippeez-M, Hipster-M, Snappeez-L
	DMC-TZ2/ TZ3	Micro, Zippeez-M, Hipster-M, Snappeez-L
	DMC-TZ4/ TZ5/ TZ50	WB Mini, Zippeez-M, Hipster-M, Snappeez-L
	DMC-TZ7	WB Mini, Zippeez-M, Hipster-M, Snappeez-L
	DMC-TZ8	WB Mini, Zippeez-M, Hipster-M, Snappeez-L
	DMC-ZR3	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-ZX1	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-ZX1	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DMC-ZX3	Mini, Zippeez-S, Hipster-S, Snappeez-M
PENTAX	LS85	Mini, Zippeez-S, Hipster-S, Snappeez-M
	*ist	D-Midsize
	*ist D	D-Midsize
	*ist DS/ *ist DL/ *istDL2	D-Midsize
	K100D/ K110D	D-Midsize
	K10D	D-SLR
	K20D/ K200D	D-Midsize
	K-7	D-Midsize
	K-m 2000 / K2000	D-Midsize
	K-x	D-Midsize
	M60	Mini, Zippeez-S, Hipster-S, Snappeez-M
	MZ-S	SLR-Auto
	Optio30	WB-Mini, Zippeez-S, Hipster-S, Snappeez-M
	Optio33L	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	Optio33LF	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	Optio33WR	WB-S
	Optio430RS	WB-Mini, Zippeez-S, Hipster-S, Snappeez-M
	Optio43WR	WB-S
	Optio450/ 550/ 555	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	Optio50	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Optio60	WB-Mini, Zippeez-S, Hipster-S
	Optio750Z	WB-Mini, Zippeez-M, Hipster-M
	OptioA10/ A20	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	OptioA30	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioA40	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioE10/ E20	WB-Mini, Zippeez-M, Hipster-M, Snappeez-M
	OptioE30	WB-Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioE40	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioE50	Mini, Zippeez-S, Hipster-S, Snappeez-M

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
PENTAX (continued)	OptioE60	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioE70	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	OptioE70L	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioE80	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioE90	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioH90	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioI-10	Zippeez-M, Hipster-M
	OptioM10	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioM30	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	OptioM40	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	OptioM50	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioM90	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioMX4	WB-S, Zippeez-M, Hipster-M
	OptioP80	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	OptioS	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	OptioS10	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioS12	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	OptioS30	WB-Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioS4/ S4i	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	OptioS40/ S45/ S55	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioS50	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioS5i	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	OptioS5Z	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	OptioS6/ S7	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	OptioS60	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioSV	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioT10/ T20/ T30	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioV10	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	OptioW10/ W20/ W30	WB-Mini, Zippeez-M, Hipster-M, Euro-S
	OptioW80 / W90	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioWP	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioWPi	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioWS80	Mini, Zippeez-S, Hipster-S, Snappeez-M
	OptioX	Zippeez-M, Hipster-M, Snappeez-L, Snappeez Horizontal-L
	OptioZ10	Mini, Zippeez-S, Hipster-S, Snappeez-M
	P70	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	PC-330/ PC-550	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	PZ-1P	D-SLR
	X70	D-Offset
	ZX-7/ ZX-5N/ ZX-50/ ZX-60/ ZX-L	SLR-Auto
	ZX-M	SLR-Manual
POLAROID	PDC-2075	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Revised
7-26-'10

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
POLAROID (continued)	PDC-2077	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	PDC-3030/ 3070	Mini, Zippeez-S, Hipster-S
	PDC-4055/ 4355/ 5355	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PDC-4370/ 5370	Mini, Zippeez-S, Hipster-S, Snappeez-M
RICOH	Capilo R10	Milli, Zippeez-S, Hipster-S, Snappeez-M
	Capilo RR730	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Caplio 500g Wide/ 500SE	D-Compact
	Caplio G3	Milli, Zippeez-L, Hipster-L, Snappeez-L
	Caplio GX8	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	Caplio R1V	Milli, Zippeez-S, Hipster-S, Snappeez-M
	Caplio R2	Milli, Zippeez-S, Hipster-S, Snappeez-M
	Caplio R3/ R4/ R5	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	Caplio R30/ R40	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	Caplio R6/ R7/ R8	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Caplio RR1	Micro, Zippeez-L, Hipster-L
	Caplio RR1	Micro, Zippeez-L, Hipster-L
	Caplio RR211	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Caplio RR30	Milli, Zippeez-L, Hipster-L, Snappeez-L
	Caplio RR530	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Caplio RR770	WB-Mini, Zippeez-S, Hipster-S, Snappeez-M
	Caplio RX	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	G600	WB-Mini, Zippeez-L, Hipster-L, Snappeez-L
	GR Digital	Milli, Zippeez-M, Hipster-M, Snappeez-L
	GR Digital II	Milli, Zippeez-M, Hipster-M, Snappeez-L
	GX200	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	R10	Mini, Zippeez-S, Hipster-S, Snappeez-M
	RDC-200G	None available at this time.
	RDC-4300	Zippeez-L, Hipster-L
	RDC-5000	Zippeez-L, Hipster-L
	RDC-5300	WB-Med, Zippeez-L, Hipster-L
	RDC-6000	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	RDC-7	Micro, Zippeez-L, Hipster-L
	RDC-i500	Zippeez-L, Hipster-L
	RDC-i700	Hipster-XL
	RDC-i700	Macro
SAMSUNG	CL65	Mini, Zippeez-S, Hipster-S, Snappeez-M
	CL80	WB Mini, Zippeez-M, Hipster-M, Snappeez-L
	Digimax 530	WB-Mini, Zippeez-M, Hipster-M
	Digimax A7/ A6/ A5	Mini, Zippeez-M, Hipster-M, Snappeez-L
	Digimax i6	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	Digimax L50/ L60	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	Digimax L85	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
SAMSUNG (continued)	Digimax S500/ S600/ S800	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Digimax V700/ V600/ V800	Mini, Zippeez-M, Hipster-M, Snappeez-L
	ES10	Mini, Zippeez-S, Hipster-S, Snappeez-M
	ES15	Mini, Zippeez-S, Hipster-S, Snappeez-M
	ES73	Mini, Zippeez-S, Hipster-S, Snappeez-M
	EX1	WB-Med, Zippeez-L, Hipster-L
	GX-10	D-SLR
	GX-1S/ GX 1L	D-Midsize
	GX-20	D-SLR
	HZ10W/ HZ15W	WB Mini, Zippeez-M, Hipster-M, Snappeez-L
	HZ30W/ HZ35W	Mini, Zippeez-M, Hipster-M, Snappeez-L
	i7	Mini, Zippeez-S, Hipster-S, Snappeez-M
	i70	Mini, Zippeez-S, Hipster-S, Snappeez-M
	i8/ i85	Mini, Zippeez-S, Hipster-S, Snappeez-M
	IT100	Mini, Zippeez-S, Hipster-S, Snappeez-M
	L100/ L110/ L210	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	L201	Mini, Zippeez-S, Hipster-S, Snappeez-M
	L310W	Mini, Zippeez-S, Hipster-S, Snappeez-M
	L700	Mini, Zippeez-S, Hipster-S, Snappeez-M
	L73/ L77	Mini, Zippeez-S, Hipster-S, Snappeez-M
	L730/ L830	Mini, Zippeez-S, Hipster-S, Snappeez-M
	L83T	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	NV OPS	Mini, Zippeez-M, Hipster-M, Snappeez-L
	NV10/ NV20/ NV15/ NV8	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	NV100HD	Mini, Zippeez-S, Hipster-S, Snappeez-M
	NV11	Mini, Zippeez-M, Hipster-M, Snappeez-L
	NV24HD	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	NV3/ NV30	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	NV4/ NV40	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	NV9	Mini, Zippeez-S, Hipster-S, Snappeez-M
	NX Series	D-Compact, D-M 4/3
	NX5 / NX10	D-Compact, D-M 4/3
	PL100/ 150	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PL50/ PL55/ PL65 / PL70	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PL80	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PL200	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PRO815	D-Midsize
	S1050	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	S1070	Mini, Zippeez-S, Hipster-S, Snappeez-M
	S630/ S730	Mini, Zippeez-S, Hipster-S, Snappeez-M
	S760/S860	Mini, Zippeez-S, Hipster-S, Snappeez-M
	S830/ S1030	Mini, Zippeez-S, Hipster-S, Snappeez-M

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Revised
7-26-'10

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
SAMSUNG (continued)	S85	Mini, Zippeez-S, Hipster-S, Snappeez-M
	S850	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	SL102	Mini, Zippeez-S, Hipster-S, Snappeez-M
	SL201	Mini, Zippeez-S, Hipster-S, Snappeez-M
	SL202	Mini, Zippeez-S, Hipster-S, Snappeez-M
	SL30	Mini, Zippeez-S, Hipster-S, Snappeez-M
	SL310W	Mini, Zippeez-S, Hipster-S, Snappeez-M
	SL420	Mini, Zippeez-S, Hipster-S, Snappeez-M
	SL502 / SL720	Mini, Zippeez-S, Hipster-S, Snappeez-M
	SL620	Mini, Zippeez-S, Hipster-S, Snappeez-M
	SL630	Mini, Zippeez-S, Hipster-S, Snappeez-M
	SL820	Mini, Zippeez-S, Hipster-S, Snappeez-M
	ST100/ ST600	Mini, Zippeez-S, Hipster-S, Snappeez-M
	ST1000	Mini, Zippeez-S, Hipster-S, Snappeez-M
	ST50	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	ST500/ ST550	Mini, Zippeez-S, Hipster-S, Snappeez-M
	ST5000/ 5500	WB Mini, Zippeez-M, Hipster-M, Snappeez-L
	ST60/ 70	Mini, Zippeez-S, Hipster-S, Snappeez-M
	TL100	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	TL105/ 110	Mini, Zippeez-S, Hipster-S, Snappeez-M
	TL205/ 210	Mini, Zippeez-S, Hipster-S, Snappeez-M
	TL220/ TL225	Mini, Zippeez-S, Hipster-S, Snappeez-M
	TL240	WB Mini, Zippeez-M, Hipster-M, Snappeez-L
	TL320	Mini, Zippeez-S, Hipster-S, Snappeez-M
	TL34HD	Mini, Zippeez-S, Hipster-S, Snappeez-M
	TL500	WB-Med, Zippeez-L, Hipster-L
	TL9	Mini, Zippeez-S, Hipster-S, Snappeez-M
	WB2000	Mini, Zippeez-M, Hipster-M, Snappeez-L
	WB500	Milli, Zippeez-S, Hipster-S, Snappeez-M
	WB5000	
	WB600/ 650	Mini, Zippeez-M, Hipster-M, Snappeez-L
	WP10	Mini, Zippeez-S, Hipster-S, Snappeez-M
SANYO	DSC-AZ1	Micro, Zippeez-M, Hipster-M, Snappeez-L
	DSC-J1	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-MZ1	Micro, Zippeez-M, Hipster-M, Snappeez-L
	DSC-S1	Mini, Zippeez-S, Hipster-S, Snappeez-M
	VPC-E6U	Mini, Zippeez-S, Hipster-S, Snappeez-M
	VPC-S5	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Xacti A5	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Xacti DSC-S3 / S4	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Xacti E6	Mini, Zippeez-S, Hipster-S, Snappeez-M
	Xacti E60 / S60	Mini, Zippeez-S, Hipster-S, Snappeez-M

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
SIGMA	DP1	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	DP2	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	SA7 SLR	SLR Auto
	SA9 SLR	SLR Auto
	SD10	D-SLR
	SD14	D-SLR
	SD15	D-SLR
	SD9	D-SLR
SONY	Alpha A100 / A200 / A290	D-Midsize
	Alpha A230/ A330/ A380 / A390	D-Midsize
	Alpha A300 / A350	D-Midsize
	Alpha A450/ A500/ A550	D-SLR
	Alpha A700	D-SLR
	Alpha A850	D-SLR
	Alpha A900	D-SLR
	DSC-F707	D-Midsize
	DSC-F717	D-Midsize
	DSC-F77	WB Mini, Zippeez-M, Hipster-M
	DSC-F828	D-Midsize
	DSC-F88	WB-Mini, Zippeez-M, Hipster-M
	DSC-G1	WB Mini, Zippeez-M, Hipster-M
	DSC-G3	WB Mini, Zippeez-M, Hipster-M
	DSC-H1	D-Small
	DSC-H10	WB-Mini, Zippeez-M, Hipster-M
	DSC-H20	WB-Mini, Zippeez-M, Hipster-M
	DSC-H3	WB-Mini, Zippeez-M, Hipster-M
	DSC-H5/ DSC-H2	D-Offset
	DSC-H50	D-Offset
	DSC-H55	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-H7/ H9	D-Offset
	DSC-HX1	D-Offset
	DSC-HX5	WB Mini, Zippeez-M, Hipster-M, Snappeez-L
	DSC-L1	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	DSC-M1	WB-Mini, Zippeez-M, Hipster-M
	DSC-M2	Milli, Zippeez-L, Hipster-L,
	DSC-N1/ N2	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-P10	Mini, Zippeez-M, Hipster-M
	DSC-P100/ DSC-P150	Mini, Zippeez-M, Hipster-M, Snappeez-L
	DSC-P200/R / P200	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-P31	WB Mini, Zippeez-M, Hipster-M, Snappeez-L
	DSC-P32/ DSC-P41	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-P52	WB-Med

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Revised
7-26-'10

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
SONY (continued)	DSC-P71	Micro, Zippeez-L, Hipster-L
	DSC-P72	WB-Mini, Zippeez-L, Hipster-L, Snappeez-L
	DSC-P73	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	DSC-P8/ DSC-P10	Mini, Zippeez-M, Hipster-M
	DSC-P92	WB-Mini, Zippeez-L, Hipster-L, Snappeez-L
	DSC-P93	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	DSC-R1	D-Midsize ????????
	DSC-S2100	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-S40	WB-Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-S60/ S90	WB-Mini, Zippeez-M, Hipster-M, Snappeez-L
	DSC-S600	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-S650/ S700/ S730/ S800	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-S750/ S780	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-S930	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-S950	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-S980	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-T1/ T3/ T7/ T33/ T5	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-T10	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-T100/ T20	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-T2	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-T200	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-T30/ T50	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-T300	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-T500	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-T700/ T77	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	DSC-T9/ T99	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	DSC-T90/ T900	Mini, Zippeez-S, Hipster-S, Snappeez-M, Snappeez Horizontal-M
	DSC-TX1/ TX5	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-TX7/ TX9	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-U30	Euro-Mini, Zippeez-S, Hipster-S, Snappeez-S
	DSC-U40/ DSC-U50	Mini, Zippeez-S, Hipster-S, Euro-S
	DSC-U60	WB-Mini, Zippeez-M, Hipster-M
	DSC-V1	WB-Med, Zippeez-L, Hipster-L
	DSC-V3	WB-Med, Zippeez-L, Hipster-L
	DSC-W1/ W5/ W7	Mini, Zippeez-S, Hipster-S
	DSC-W100	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-W120/ W130	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-W150/ W170	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-W180/ W190	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-W210/ W220	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-W230/ W270/ W290	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-W30/ W50	Mini, Zippeez-S, Hipster-S, Snappeez-M

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.

OP/TECH USA®

Camera/Pouch Recommendation Chart

Manufacturer	Model	OP/TECH USA Pouch Recommendation
SONY (continued)	DSC-W300	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-W35/ W55	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-W380	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	DSC-W70	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-W80/ W90/ W200	Mini, Zippeez-S, Hipster-S, Snappeez-M
	DSC-WX1/ WX5	Euro Mini, Zippeez-S, Hipster-S, Snappeez-S
	DSLR-A200	D-Midsize
	NEX-3 / NEX-5	D M-4/3
TOSHIBA	PDR-3310	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PDR-3330	Zippeez-M, Hipster-M
	PDR-4300	WB-Med, Zippeez-L, Hipster-L
	PDR-5300	Mini, Zippeez-S, Hipster-S, Snappeez-M
	PDR-M1	Zippeez-L, Hipster-L
	PDR-M11	Zippeez-M, Hipster-M
	PDR-M21	Zippeez-M, Hipster-M
	PDR-M25	WB-S, Zippeez-M, Hipster-M
	PDR-M3	WB-Med, Zippeez-L, Hipster-L
	PDR-M4	WB-Mini, Zippeez-M, Hipster-M
	PDR-M5	D-Compact
	PDR-M60	WB-Med, Zippeez-L, Hipster-L
	PDR-M61	WB-Med, Zippeez-L, Hipster-L
	PDR-M65	WB-Med, Zippeez-L, Hipster-L
	PDR-M70	WB-Med, Zippeez-L, Hipster-L
	PDR-M71	WB-Mini, Zippeez-M, Hipster-M
	PDR-M81	WB-Mini, Zippeez-M, Hipster-M
	PDR-T10	Mini, Zippeez-S, Hipster-S, Snappeez-M

Note: OP/TECH USA Pouch recommendations are based on advertised camera dimensions. Due to variations in camera shape and optional accessories you may require a different size.